



Ref#	Item #	Description
1A	42-530-01	Crankcase, Set Pins, & Plate
2	42-530-02	Piston Oil Seal
5	42-530-05	Screw For Crankshaft Oil Seal Cover
6	42-530-06	Oil Seal Cover
7A	42-530-07	Oil Inlet Cover
8	42-530-08	Gasket for Rear Crankcase Cover
9	42-530-09	Crankcase Rear Cover
10	42-530-10	Screw for Crankshaft Rear Cover
11A	42-530-11	Oil Window Assembly
12A	42-530-12	Oil Drainage Plug
13	42-530-13	Crankshaft Key
14	42-530-14	Crankshaft
15A	42-530-15	Connecting Rod Assembly
16	42-530-16	Crankshaft Bearing,
17	42-530-17	Crankshaft Oil Seal
18	42-530-18	Crankshaft Cover
19A	42-530-19	Piston Assembly
26	42-530-26	Piston Pin
28*	42-530-28S	Short Pump Stands (pair)
28*	42-530-28T	Tall Pump Stands (pair)

Ref#	Item #	Description
29A	42-530-29	Bolt, Washer, & Lock Washer
31A	42-530-31	Pulley with Bolt Set
41A	42-530-41	Bolt & Lock Washer
42A	42-530-42	Double End Screw, Nut, & Lock Washer
51A	42-530-51	Suction Chamber Assembly
53A	42-530-53	Bolt & Washer
60A	42-530-60	Connecting Hose with O-Ring
65	42-530-65	Outlet Chamber
70	42-530-70	3/8" Brass Plug
75	42-530-75	Air Chamber Surge Tank with O-Ring
76	FT-GAL-SE14	1/4" Street Elbow
77	FT-TW12B	1/2" MNPT x 1/2" HB Swivel
78	FT-3LL34	3/4"x3/4" FNPT Fitting
79	FT-3A34	3/4" MNPT x 3/4" HB Poly Fitting
200	43-530-200	Pressure Regulator Assembly
335	43-530-335	Cylinder Head w/ Preinstalled Packing
350	43-530-350	Replacement Valve Kit (6pcs)
NA	43-530-380	Rebuild Kit (ref #s 350 & 325)
NA	43-530-400	Master Rebuild Kit (ref #s 350 & 335)
600	42-950-600	0-600psi Pressure Gauge