



| Ref# | Item #                    | Description                         |
|------|---------------------------|-------------------------------------|
| 1A   | <a href="#">42-550-01</a> | Crankcase, Set Pins, & Plate        |
| 2    | <a href="#">42-550-02</a> | Piston Oil Seal                     |
| 3    | <a href="#">42-550-03</a> | Dust Cover                          |
| 5    | 42-530-05                 | Screw For Crankshaft Oil Seal Cover |
| 6    | <a href="#">42-550-06</a> | Oil Seal Cover                      |
| 7A   | <a href="#">42-550-07</a> | Oil Inlet Cover                     |
| 8    | <a href="#">42-550-08</a> | Gasket for Rear Crankcase Cover     |
| 9    | 42-550-09                 | Rear Cover                          |
| 10   | 42-530-10                 | Screw for Crankshaft Rear Cover     |
| 11A  | <a href="#">42-530-11</a> | Oil Window Assembly                 |
| 12A  | <a href="#">42-530-12</a> | Oil Drainage Plug Assembly          |
| 13   | <a href="#">42-530-13</a> | Crankshaft Key                      |
| 14   | 42-550-14                 | Crankshaft                          |
| 15A  | <a href="#">42-550-15</a> | Connecting Rod Assembly             |
| 16   | <a href="#">42-550-16</a> | Crankshaft Bearing                  |
| 17   | <a href="#">42-550-17</a> | Crankshaft Oil Seal                 |
| 18   | <a href="#">42-530-18</a> | Crankshaft Cover                    |
| 19A  | <a href="#">42-550-19</a> | Piston Assembly                     |
| 26   | 42-550-26                 | Piston Pin                          |
| 28   | <a href="#">42-550-28</a> | Pump Stands (Sold in pairs)         |

| Ref# | Item #                      | Description                                    |
|------|-----------------------------|--|
| 31A  | <a href="#">42-550-31</a>   | Pulley with Bolt Set                           |
| 42A  | <a href="#">42-550-42</a>   | Double End Screw, Nut, & Lock Washer           |
| 51A  | 42-550-51                   | Suction Chamber Assembly                       |
| 60A  | <a href="#">42-530-60</a>   | Connecting Hose with O-Ring                    |
| 61A  | 42-530-61                   | Connecting Hose w/ O-Rings (Large)             |
| 62A  | 42-530-62                   | Connecting Hose w/ O-Rings (Small)             |
| 65   | <a href="#">42-550-65</a>   | Outlet Chamber                                 |
| 70   | FT-F12B                     | 1/2" Brass Plug                                |
| 75A  | <a href="#">42-550-75</a>   | Air Chamber Surge Tank with O-Ring             |
| 76   | <a href="#">FT-GAL-SE14</a> | 1/4" Street Elbow                              |
| 77   | <a href="#">FT-TW12B</a>    | 1/2" MNPT x 1/2" HB Swivel                     |
| 78   | <a href="#">FT-3LL34</a>    | 3/4"x3/4" FNPT Fitting                         |
| 79   | <a href="#">FT-3A34</a>     | 3/4" MNPT x 3/4" HB Poly Fitting               |
| 200  | <a href="#">43-530-200</a>  | Pressure Regulator Assembly (Incl'd 61A & 62A) |
| 535  | <a href="#">43-550-535</a>  | Cylinder Head w/ Preinstalled Packing          |
| 550  | <a href="#">43-550-550</a>  | Replacement Valve Kit (6pcs)                   |
| NA   | <a href="#">43-550-580</a>  | Rebuild Kit (Ref #s 550 & 525)                 |
| NA   | <a href="#">43-550-600</a>  | Master Rebuild Kit (Ref #s 550 & 535)          |
| 600  | <a href="#">42-950-600</a>  | 0-600psi Pressure Gauge                        |