



Ref#	Item #	Description
1A	42-550-01	Crankcase, Set Pins, & Plate
2	42-550-02	Piston Oil Seal
3	42-550-03	Dust Cover
5	42-530-05	Screw For Crankshaft Oil Seal Cover
6	42-550-06	Oil Seal Cover
7A	42-550-07	Oil Inlet Cover
8	42-550-08	Gasket for Rear Crankcase Cover
9	42-550-09	Rear Cover
10	42-530-10	Screw for Crankshaft Rear Cover
11A	42-530-11	Oil Window Assembly
12A	42-530-12	Oil Drainage Plug Assembly
13	42-530-13	Crankshaft Key
14	42-550-14	Crankshaft
15A	42-550-15	Connecting Rod Assembly
16	42-550-16	Crankshaft Bearing
17	42-550-17	Crankshaft Oil Seal
18	42-530-18	Crankshaft Cover
19A	42-550-19	Piston Assembly
26	42-550-26	Piston Pin
28	42-550-28	Pump Stands (pair)

Ref#	Item #	Description
29A	42-530-29	Bolt & Washer
31A	42-550-31	Pulley with Bolt Set
41	42-550-41	Bolt & Washer
42A	42-550-42	Double End Screw, Nut, & Lock Washer
51A	42-550-51	Suction Chamber Assembly
53A	42-550-53	Bolt & Washer
60A	42-530-60	Connecting Hose with O-Ring
65	42-550-65	Outlet Chamber
70	FT-F12B	1/2" Brass Plug
75A	42-550-75	Air Chamber Surge Tank with O-Ring
76	FT-GAL-SE14	1/4" Street Elbow
77	FT-TW12B	1/2" MNPT x 1/2" HB Swivel
78	FT-3LL34	3/4" x 3/4" FNPT Fitting
79	FT-3A34	3/4" MNPT x 3/4" HB Poly Fitting
200	43-530-200	Pressure Regulator Assembly
535	43-550-535	Cylinder Head w/ Preinstalled Packing
550	43-550-550	Replacement Valve Kit (6pcs)
NA	43-550-580	Rebuild Kit (Ref #s 550 & 525)
NA	43-550-600	Master Rebuild Kit (Ref #s 550 & 535)
600	42-950-600	0-600psi Pressure Gauge